

Television Remote Control

Power
Press to turn television
ON and **OFF**

Volume UP
Volume DOWN

MENU

GO BACK

Channel UP
Channel DOWN

ENTER

Menu Navigation Keys

STOP

PAUSE

Movie Controls

